

Rudy's

**** Instant use, high strength, ABS Patches ****

ABS Quick Patch Kit

- **Installs in about 1 minute** - No tools required! Just clean with alcohol, peel and stick base down
- **Stops or slows cracked plastic run-out in Lids, Fairings, Doors and Cover Panels**
- Install once and forget it from then on. 140 lb. adhesive tensile strength.
- Won't rattle or make noise. **6 patches and 3M Adhesion Promoter included!**
- No holes required – Just clean plastic landing zone with isopropyl alcohol and attach.
- 2 Year Materials and Workmanship Warranty!

Congratulations on the purchase of your ABS Quick Patch kit. This super strong and easy to install kit will save you countless headaches and money by preventing and repairing cracks in your motorcycle and automotive plastics. It is a one time install system to provide years of trouble free strength for your motorcycle and other vehicles where plastics are stressed and tend to crack.



Installation:

Warning: Successful adhesion is critical. Failure to follow these steps for preparation of the panel to adhere to the special adhesive patch will likely be cause for failure of the adhesive and possible loss of the part being patched!!! This adhesive is rated at 140 lbs tensile strength and installed temps of -40F to 200F but ONLY if it is installed properly. We will not be responsible for adhesion failure due to improper preparation procedures. **DO NOT** touch the tape surface or the cleaned contact location with your fingers! Anywhere you do touch the tape or cleaned contact area will reduce your effective contact surface by that much.

Please follow the instructions, below...

1. Gain access to the rear of the panel needing support. The base must be attached to the plastic of the part being patched since paint and other surfaces are not strong enough to hold under stress.
2. Clean the inner wall with a paper towel and isopropyl alcohol after sanding and steel wooling any coatings from the plastic surface being repaired. The plastic surface must be smooth. Let the alcohol dry completely.
3. If using the 3M Adhesion Promoter packet, do not allow the contents of the package to touch your skin. Tear the packet where marked and use the sponge like a paint brush to apply a thin coating to the surface needed. Do not over apply. Packet is a use and dispose product and cannot be saved once opened. There is enough in one packet to do all 6 patch locations if they are all prepared in advance when the packet is opened. Allow the liquid to dry 10 minutes before applying a Quick Patch to it.

4. Mount the base to the area needing support where it was cleaned. You can immediately use the system once the base is attached. You may stack or stagger patches on top of each other for additional strength if the surface being attached to has been cleaned of all oil and debris using isopropyl alcohol. You only get one chance to place the patch so make sure you place it where you want it the first time and that the surface is relatively flat for maximum contact.
5. Unused patches may be stored for up to one year.

Please contact us about any questions or problems you may have with your ABS Quick Patch kit installation or operation at support@thefarend.com Any comments or suggestions are always welcome.

We have done our best to make this kit as complete, reliable and easy to install as possible for you.

Please look for other Rudy's Quick Patches and Reinforcement Kits to meet all of your ABS repair and prevention needs.

Thanks for purchasing Rudy's ABS Quick Patch kit.